

Potentiometer Basics

Definition	Key Components	Operation
<p>A potentiometer (or pot) is a three-terminal resistor with a sliding or rotating contact that forms an adjustable voltage divider.</p> <p>It acts as a variable resistor, allowing you to adjust the resistance value by turning a knob or slider.</p>	<p>Resistive Element: A track of resistive material (carbon composition, cermet, wirewound) determining the total resistance.</p> <p>Wiper (Sliding Contact): A movable contact that slides along the resistive element, tapping off a fraction of the total resistance.</p> <p>Terminals: Three terminals: two connected to the ends of the resistive element, and one connected to the wiper.</p>	<p>By adjusting the position of the wiper, the resistance between the wiper and one end terminal changes. This allows a fraction of the applied voltage to be tapped off.</p> <p>When used as a potentiometer, all three terminals are connected. When used as a variable resistor (rheostat), only two terminals are used (one end and the wiper).</p>
<p>Symbol</p> <p>https://upload.wikimedia.org/wikipedia/commons/thumb/1/1c/Potentiometer_symbols.svg/1280px-Potentiometer_symbols.svg.png</p> <p>Schematic symbol for potentiometer</p>		

Types of Potentiometers

Based on Resistive Material	Based on Mechanical Configuration
<p>Carbon Film: Low cost, general purpose, higher noise. Typically used in audio controls and low-precision applications.</p> <p>Cermet: Good stability, higher precision, lower noise than carbon film. Used in precision circuits and trimmers.</p> <p>Wirewound: High power rating, high precision, but limited resolution. Used in high-power applications and precision control.</p> <p>Conductive Plastic: Low noise, long life, moderate precision. Used in high-end audio equipment and precision controls.</p>	<p>Rotary Potentiometers: Adjusted by rotating a shaft. Common in volume controls, user interfaces.</p> <p>Slider Potentiometers: Adjusted by sliding a knob linearly. Used in audio mixers and graphic equalizers.</p> <p>Trimmer Potentiometers (Trimpots): Small potentiometers designed for infrequent adjustments, often used for calibration purposes on PCBs.</p> <p>Multi-turn Potentiometers: Require multiple rotations of the shaft to cover the full resistance range, allowing for finer adjustments. Used in precision instrumentation.</p>

Key Specifications

Electrical Characteristics	Environmental Considerations
<p>Total Resistance: The overall resistance between the two end terminals, typically ranging from a few ohms to several megaohms.</p> <p>Tolerance: The allowable variation in the total resistance, expressed as a percentage (e.g., $\pm 10\%$).</p> <p>Power Rating: The maximum power the potentiometer can dissipate without damage, typically expressed in watts.</p> <p>Taper (Linear/Logarithmic): Describes the relationship between the wiper position and the resistance. Linear taper means resistance changes linearly with position; logarithmic taper (audio taper) means resistance changes logarithmically.</p> <p>Resolution: The smallest possible change in resistance that can be achieved. Wirewound pots have lower resolution than film pots.</p>	<p>Temperature Coefficient: Describes how much the resistance changes with temperature. Important for high-precision applications.</p> <p>Operating Temperature Range: The range of temperatures within which the potentiometer will function correctly.</p> <p>Humidity Sensitivity: How much the resistance changes with humidity.</p>

Applications

Volume controls in audio equipment.
Brightness/contrast adjustments in displays.
Calibration trimmers in circuits.
Position feedback sensors in robotics.
Adjustable voltage dividers.

Circuit Examples

Voltage Divider:	A potentiometer connected to a voltage source provides an adjustable output voltage. $V_{out} = V_{in} * (R2 / (R1 + R2))$ where R2 is the resistance between the wiper and ground.
Rheostat:	A potentiometer used as a two-terminal variable resistor can control current in a circuit (e.g., dimming an LED).

Practical Considerations

Always select a potentiometer with a suitable power rating for the application to prevent overheating.
Consider the required precision and stability when choosing between different potentiometer types (e.g., carbon film vs. cermet).
Use a linear taper for general-purpose adjustments and a logarithmic taper (audio taper) for volume controls.