

Circuit Analysis Fundamentals

Basic Circuit Elements

Resistor (R)	Opposition to current flow. Measured in Ohms ( $\Omega$ ). Ohm's Law: $V = IR$
Capacitor (C)	Stores electrical energy. Measured in Farads (F). $I = C(dV/dt)$
Inductor (L)	Stores energy in a magnetic field. Measured in Henries (H). $V = L(dI/dt)$
Voltage Source (V)	Provides a constant voltage. Ideal voltage source has zero internal resistance.
Current Source (I)	Provides a constant current. Ideal current source has infinite internal resistance.

Circuit Laws

Kirchhoff's Current Law (KCL)	The algebraic sum of currents entering a node is zero. $\sum I = 0$
Kirchhoff's Voltage Law (KVL)	The algebraic sum of voltages around a closed loop is zero. $\sum V = 0$
Ohm's Law	Relates voltage, current, and resistance: $V = IR$
Power (P)	Rate at which energy is transferred. $P = VI = I^2R = V^2/R$
Series Resistors	Equivalent resistance: $R_{eq} = R_1 + R_2 + \dots + R_n$
Parallel Resistors	Equivalent resistance: $1/R_{eq} = 1/R_1 + 1/R_2 + \dots + 1/R_n$

Circuit Analysis Techniques

Nodal Analysis:	Solve for node voltages using KCL. Choose a reference node (ground).
Mesh Analysis:	Solve for loop currents using KVL. Suitable for planar circuits.
Superposition Theorem:	Find the response due to each independent source acting alone, then sum the individual responses. Only applicable for linear circuits.
Thevenin's Theorem:	Replace a complex circuit with a voltage source ( $V_{th}$ ) in series with a resistor ( $R_{th}$ ).
Norton's Theorem:	Replace a complex circuit with a current source ( $I_n$ ) in parallel with a resistor ( $R_n$ ). $R_n = R_{th}$

Electromagnetics

Fundamental Constants

Permittivity of Free Space ( $\epsilon_0$ )	$\epsilon_0 \approx 8.854 \times 10^{-12}$ F/m
Permeability of Free Space ( $\mu_0$ )	$\mu_0 = 4\pi \times 10^{-7}$ H/m
Speed of Light (c)	$c \approx 3 \times 10^8$ m/s

Magnetostatics

Magnetic Field (B)	Measured in Tesla (T) or Webers per square meter (Wb/m <sup>2</sup> )
Magnetic Force (F)	On a moving charge: $F = q(v \times B)$
Ampère's Law	Relates magnetic field to current: $\oint B \cdot dl = \mu_0 I_{enc}$
Inductance (L)	Ability of a conductor to store energy in a magnetic field: $L = \Phi/I$ (Henries)

Electromagnetic Waves

Maxwell's Equations (Differential Form):	<div><math>\nabla \cdot D = \rho</math></div> <div><math>\nabla \cdot B = 0</math></div> <div><math>\nabla \times E = -\partial B/\partial t</math></div> <div><math>\nabla \times H = J + \partial D/\partial t</math></div>
Poynting Vector (S):	Represents the power flow of an electromagnetic wave. $S = E \times H$ (W/m <sup>2</sup> )
Wave Impedance ( $\eta$ ):	Ratio of electric field to magnetic field in a medium. $\eta = \sqrt{\mu/\epsilon}$

Electrostatics

Electric Field (E)	Force per unit charge. $E = F/q$ (N/C or V/m)
Electric Potential (V)	Potential energy per unit charge. $V = U/q$ (Volts)
Coulomb's Law	Force between two point charges: $F = k * (q_1 q_2) / r^2$ , where $k = 1 / (4\pi\epsilon_0)$
Capacitance (C)	Charge stored per unit voltage: $C = Q/V$ (Farads)

Digital Logic

Basic Logic Gates

AND Gate	Output is 1 only if all inputs are 1.
OR Gate	Output is 1 if at least one input is 1.
NOT Gate	Inverts the input. If input is 1, output is 0, and vice versa.
NAND Gate	NOT + AND. Output is 0 only if all inputs are 1.
NOR Gate	NOT + OR. Output is 1 only if all inputs are 0.
XOR Gate	Exclusive OR. Output is 1 if inputs are different.

Boolean Algebra

<b>Basic Theorems:</b>
$A + 0 = A$
$A + 1 = 1$
$A \cdot 0 = 0$
$A \cdot 1 = A$
$A + A = A$
$A \cdot A = A$
<b>Commutative Laws:</b>
$A + B = B + A$
$A \cdot B = B \cdot A$
<b>Associative Laws:</b>
$(A + B) + C = A + (B + C)$
$(A \cdot B) \cdot C = A \cdot (B \cdot C)$
<b>Distributive Laws:</b>
$A \cdot (B + C) = A \cdot B + A \cdot C$
$A + (B \cdot C) = (A + B) \cdot (A + C)$
<b>DeMorgan's Theorems:</b>
$(A + B)' = A' \cdot B'$
$(A \cdot B)' = A' + B'$

Power Systems

AC Power Fundamentals

<b>RMS Voltage (Vrms)</b>	Root Mean Square voltage. $V_{rms} = V_{peak} / \sqrt{2}$ (for sinusoidal waveforms)
<b>RMS Current (Irms)</b>	Root Mean Square current. $I_{rms} = I_{peak} / \sqrt{2}$ (for sinusoidal waveforms)
<b>Apparent Power (S)</b>	$S = VI^*$ (VA)
<b>Real Power (P)</b>	$P = VI \cos(\theta)$ (Watts)
<b>Reactive Power (Q)</b>	$Q = VI \sin(\theta)$ (VARs)
<b>Power Factor (PF)</b>	$PF = \cos(\theta) = P /  S $

Transformers

<b>Turns Ratio (a):</b>	$a = N_p / N_s = V_p / V_s = I_s / I_p$ Np, Ns: Number of turns in primary and secondary windings. Vp, Vs: Voltage in primary and secondary windings. Ip, Is: Current in primary and secondary windings.
<b>Ideal Transformer Equation:</b>	$V_p \cdot I_p = V_s \cdot I_s$

Combinational Logic Circuits

<b>Multiplexers (MUX):</b> Select one of several input signals and forward it to the output.
<b>Demultiplexers (DEMUX):</b> Direct a single input signal to one of several outputs.
<b>Encoders:</b> Convert a set of inputs into a binary code.
<b>Decoders:</b> Convert a binary code into a set of outputs.
<b>Adders:</b> Perform binary addition (Half Adder, Full Adder).

Sequential Logic Circuits

<b>Flip-Flops:</b> Basic memory elements (SR, D, JK, T).
<b>Registers:</b> Groups of flip-flops used to store binary information.
<b>Counters:</b> Sequential circuits that count pulses (Asynchronous, Synchronous).

Three-Phase Power

<b>Line Voltage (V_L)</b>	Voltage between two lines in a three-phase system.
<b>Phase Voltage (V_ph)</b>	Voltage across a single phase.
<b>Line Current (I_L)</b>	Current flowing through a line in a three-phase system.
<b>Phase Current (I_ph)</b>	Current flowing through a single phase.
<b>Y-Connection</b>	$V_L = \sqrt{3} \cdot V_{ph}$ , $I_L = I_{ph}$
<b>Delta-Connection</b>	$V_L = V_{ph}$ , $I_L = \sqrt{3} \cdot I_{ph}$
<b>Three-Phase Power (P)</b>	$P = \sqrt{3} \cdot V_L \cdot I_L \cdot \cos(\theta)$

Power System Protection

<b>Fuses:</b> Overcurrent protection. Melt and interrupt the circuit.
<b>Circuit Breakers:</b> Overcurrent protection. Can be reset after tripping.
<b>Relays:</b> Detect abnormal conditions and initiate protective actions.
<b>Grounding:</b> Provides a low-impedance path for fault currents.